

**SKIP\*HOP**® **MOBY**™  
bath spout cover

**INSTRUCTIONS**

1. Slip Moby over spout, so water flow is not obstructed.  
(if you have a shower diverter, it should be visible from the top)
2. If Moby does not feel secure, pull fin on far side taut while holding Moby in place.  
(NOTE: If Moby does not completely cover end of spout, do not use.)

©2008 Skip Hop  
[www.skiphop.com](http://www.skiphop.com)  
IN THE US: 1-877-4-SKIPHOP